

Stainless steel platform scale KERN SFB-H · SFB



Stainless steel platform scales with IP65/67 protection, also with XL platform or EC type approval [M]

**Features**

- Ideal for the robust industrial applications
- **1** Platform: made entirely of stainless steel, silicone-coated Stainless Steel load cell, protection against dust and water splashes IP67
- **2** Display device: Stainless steel, protection against dust and water splashes IP65, (only when using rechargeable battery pack)
- **3** SFB-H: Column, standard, for models with weighing plate size  
300×240 mm: Height of stand approx. 200 mm  
400×300 mm: Height of stand approx. 400 mm


**Technical data**

- Large backlit LCD display, digit height 52 mm
- Dimensions of display device W×D×H 266×165×96 mm
- Cable length of display device approx. 3 m
- Internal rechargeable battery pack, operating time up to 35 h without backlight, charging time approx. 12 h
- Permissible ambient temperature -10 °C/40 °C

**Accessories**

- Data interface RS-232, interface cable included, approx. 1,5 m, must be ordered at purchase, RS 232 data interface including interface cable, KERN KFN-A01
- Stand to be screwed onto the platform, height of stand approx. 600 mm, KERN SFB-A01
- **4** Stand to elevate display device, height of stand approx. 800 mm, KERN BFS-A07
- Further details, plenty of further accessories and suitable printers see Accessories


STANDARD



OPTION



FACTORY



Model	Weighing capacity [Max] kg	Readability [d] g	Verification value [e] g	Minimal load [Min] g	Net weight approx. kg	Weighing plate W×D	Option			
							Verification		DAkkS Calibr. Certificate	
<b>KERN</b>							<b>M</b>		<b>DAkkS</b>	
SFB 50K-3XL	50	5	-	-	14	500×400	-		KERN	963-128
SFB 100K-2XL	100	10	-	-	24	650×500	-			963-129
with elevated display										
SFB 10K1HIP	10	1	-	-	8	300×240	-			963-128
SFB 20K2HIP	20	2	2	-	8	300×240	-			963-128
SFB 50K5HIP	50	5	5	-	8	300×240	-			963-128
SFB 50K5LHIP	50	5	5	-	10	400×300	-			963-128
SFB 100K10HIP	100	10	-	-	10	400×300	-			963-129
Note: For applications that require verification, please order verification at the same time, initial verification at a later date is not possible. Verification at the factory, we need to know the full address of the location of use.										
SFB 60K-2XLM	60	20	20	400	14	500×400	965-229			963-129
SFB 100K-2XLM	150	50	50	1000	24	650×500	965-229			963-129
with elevated display										
SFB 15K5HIPM	15	5	5	100	8	300×240	965-228			963-128
SFB 30K10HIPM	30	10	10	200	8	300×240	965-228			963-128
SFB 60K20LHIPM	60	20	20	400	10	400×300	965-229			963-129
SFB 100K-2HM	150	50	50	1000	10	400×300	965-229			963-129

**Pictograms**

<p><b>Internal adjusting:</b> Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)</p>	<p><b>KERN Communication Protocol (KCP):</b> It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems</p>	<p><b>Suspended weighing:</b> Load support with hook on the underside of the balance</p>
<p><b>Adjusting program CAL:</b> For quick setting up of the balance's accuracy. External adjusting weight required</p>	<p><b>GLP/ISO log:</b> The balance displays serial number, user ID, weight, date and time, regardless of a printer connection</p>	<p><b>Battery operation:</b> Ready for battery operation. The battery type is specified for each device</p>
<p><b>Easy Touch:</b> Suitable for the connection, data transmission and control through PC, tablet or smartphone.</p>	<p><b>GLP/ISO log:</b> With weight, date and time. Only with KERN printers</p>	<p><b>Rechargeable battery pack:</b> Rechargeable set</p>
<p><b>Memory:</b> Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.</p>	<p><b>Piece counting:</b> Reference quantities selectable. Display can be switched from piece to weight</p>	<p><b>Universal mains adapter:</b> with universal input and optional input socket adapters for A) EU, CH, GB; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS</p>
<p><b>Alibi memory:</b> Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard</p>	<p><b>Recipe level A:</b> The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out</p>	<p><b>Mains adapter:</b> 230V/50Hz in standard version for EU, CH. On request GB, USA or AUS version available</p>
<p><b>Data interface RS-232:</b> To connect the balance to a printer, PC or network</p>	<p><b>Recipe level B:</b> Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display</p>	<p><b>Power supply:</b> Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request</p>
<p><b>RS-485 data interface:</b> To connect the balance to a printer, PC or other peripherals. Suitable for data transfer over large distances. Network in bus topology is possible</p>	<p><b>Totalising level A:</b> The weights of similar items can be added together and the total can be printed out</p>	<p><b>Weighing principle: Strain gauges:</b> Electrical resistor on an elastic deforming body</p>
<p><b>USB data interface:</b> To connect the balance to a printer, PC or other peripherals</p>	<p><b>Percentage determination:</b> Determining the deviation in % from the target value (100 %)</p>	<p><b>Weighing principle: Tuning fork:</b> A resonating body is electromagnetically excited, causing it to oscillate</p>
<p><b>Bluetooth* data interface:</b> To transfer data from the balance to a printer, PC or other peripherals</p>	<p><b>Weighing units:</b> Can be switched to e.g. nonmetric units at the touch of a key. See balance model. Please refer to KERN's website for more details</p>	<p><b>Weighing principle: Electromagnetic force compensation:</b> Coil inside a permanent magnet. For the most accurate weighings</p>
<p><b>WiFi data interface:</b> To transfer data from the balance to a printer, PC or other peripherals</p>	<p><b>Weighing with tolerance range:</b> (Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model</p>	<p><b>Weighing principle: Single cell technology:</b> Advanced version of the force compensation principle with the highest level of precision</p>
<p><b>Control outputs (optocoupler, digital I/O):</b> To connect relays, signal lamps, valves, etc.</p>	<p><b>Hold function:</b> (Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value</p>	<p><b>Verification possible:</b> The time required for verification is specified in the pictogram</p>
<p><b>Analogue interface:</b> to connect a suitable peripheral device for analogue processing of the measurements</p>	<p><b>Protection against dust and water splashes IPxx:</b> The type of protection is shown in the pictogram</p>	<p><b>DAKkS calibration possible (DKD):</b> The time required for DAKkS calibration is shown in days in the pictogram</p>
<p><b>Interface for second balance:</b> For direct connection of a second balance</p>	<p><b>Factory calibration (ISO):</b> The time required for Factory calibration is shown in days in the pictogram</p>	<p><b>Package shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram</p>
<p><b>Network interface:</b> For connecting the scale to an Ethernet network</p>	<p><b>Pallet shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram</p>	<p><b>Pallet shipment:</b> The time required for internal shipping preparations is shown in days in the pictogram</p>

\*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.

**KERN – Precision is our business**

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAKkS calibration certificate the best pre-requisite for proper balance calibration.

The KERN DAKkS calibration laboratory today is one of the most modern and best-equipped DAKkS calibration laboratories for balances, test weights and force-measurement in Europe.

Thanks to the high level of automation, we can carry out DAKkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

**Range of services:**

- DAKkS calibration of balances with a maximum load of up to 50 t
- DAKkS calibration of weights in the range of 1 mg - 2500 kg
- Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
- Calibration of force-measuring devices
- DAKkS calibration certificates in the following languages DE, EN, FR, IT, ES, NL, PL
- Conformity evaluation and reverification of balances and test weights

**Your KERN specialist dealer:**