mediclinics

HAND DRYERS

SENSOR OPERATED

Smartflow M04A



General description


- The economic line of Smartflow® hand dryers is one of the most compact in the market, designed for locations that because of their size require small sized washroom accessories that meet two requirements: low consumption and optimum hand drying.
- These units are automatic dryers that offer an optimum relationship between functionality and price. Because of its features and design, this economic line is intended to be installed in areas with a medium traffic of people like for example medium sized restaurants, cafeterias or the offices of a small or medium sized company.
- Four models with different finishes are available: white, matte black, bright and satin. All of them with an ABS resistant cover and electronic detection sensor by infrared beam with adjustable distance detection, that allows a better adaptability to different types of washrooms.
- These dryers also provide maximum safety, with a safety thermal cut off installed in the motor and another one in the dryer's heating element.

Components and materials

- **M04A:** White ABS thermoplastic one-piece cover, 3 mm thick. Cover fixed to the base by means of 2 screws.
- **M04AB:** Matte black ABS thermoplastic one-piece cover, 3 mm thick. Cover fixed to the base by means of 2 screws.
- **M04AC:** Bright finish ABS thermoplastic one-piece cover, 3 mm thick. Cover fixed to the base by means of 2 screws.
- **M04ACS:** Satin finish ABS thermoplastic one-piece cover, 3 mm thick. Cover fixed to the base by means of 2 screws.
- BASE PLATE: made of thermoplastic PP + talcum with 4 Ø 6 mm holes for wall mounting.
- MOTOR: universal brush motor, 15,000 rpm, which includes a safety thermal cut-off.
- FAN WHEEL: fire resistant plastic PP-V0 helicoidal fan wheel.
- **HEATING ELEMENT:** waved wire NiCr heating element on a mica frame that incorporates a safety thermal cut-off.
- **DETECTION SENSOR:** fully adjustable (5-25 cm) IR electronic detection sensor by means of a potentiometer.

/oltage	220- 240 V
Frequency	50/60 Hz
Electrical Isolation	Class II
otal power	1,100 W
Consumption	4.8 A
Motor power	150 W
Rpm	15,000
Heating element power	950 W
Dimensions	259x147x138 mm.
Veight	1.2 Kg
over thickness	3 mm
Drying time	39 sec.
Effective airflow	102 m³/h (1,700 L/min)
Air velocity	100 Km/h
Air temperature (10 cm listance/21ºC)	55 °C
Sound pressure (at 2m)	67 dBA
Protection rating	IP23

Dimensions




Dimensions: ± 4

Place the hands under the air outlet. The dryer will start automatically, and go on with no interruption as long as the hands are kept in the detection range of the sensor. The appliance will stop 2 seconds after the hands are removed from the airflow.

Mounting

Recommended heights distance from the floor



Certificates and qualifications



Mediclinics, S.A., reserves the right to make changes and/or modifications to the products and their specifications without prior notice. Review 10-20 © mediclinics S.A.

